

FIG. I Ref.	Part Name	No. of Fitting	Type of Lubrication	Lube or Change	Remarks
47	Diesel Fuel Fill	1	Diesel Fuel	—	—
48	Transmission Drain, Fill Oil Level	1	Mobil ATF 220	500 Hrs.	Fill to Plug Level
49	Rear Axle Disc. Cable Trans End	1	Mobilgrease Special	40 Hrs.	Check 8 Hrs.
50	Diesel Fuel Drain	1	—	—	—
51	Transmission Oil Filter	1	Trans. Oil Filter Element	500 Hrs.	—
52	Shipper Pivot Pin	2	Mobilgrease Special	40 Hrs.	—
53					
54	Winch Fill Plug	1	AGMA #8 Compound	—	—
55	Winch Check Plug	1	—	250 Hrs.	—
56	" Drain Plug	1	—	—	—
57	" Guide Roller	2	Mobilgrease Special	40 Hrs.	—
58	Winch Drum	1	" "	40 Hrs.	—
59	Governor Control Cable (ENG. END)	1	" "	40 Hrs.	—
60	Engine Oil Filter	1	Oil Filter Element	—	—
61	" Oil Filler Cap	1	Mobil Delvac 1220&1230 (See Mfg. Operators Manual)	—	—
62	Engine Oil Dipstick	1	—	—	—
63	" Oil Drain Plug	1	—	—	—
64	Drive Shaft Universal (Engine to Pump)	2	Mobilgrease Special	40 Hrs.	—
65	Outrigger Arm Pivot	1	" "	40 Hrs.	4 Places
66	" Cyl. Rod End	1	" "	40 Hrs.	4 Places
67	Air Cleaner			100 Hrs.	See Chapter on Eng. Air Cleaner
68	Outrigger Cyl. Tube End	3	Mobilgrease Special	40 Hrs.	2 Places
69	Pump Gear Case Disconnect Cable	1	Mobilgrease Special	40 Hrs.	—
70	2 Pump Gear Case oil Drain	1	—	—	—